



Manual de armado




Ref.: 1416INF

A		18
B		16
C		76
D		05
E		50
F		04
G		12
H		06
I		12
J		05
K		04
L		04
M		06
N		03
O		03
P		04


1




2




3



4



5



6 2x

